



Revised 1.7.09

## 2009 PullRite Receiver Hitch Application Chart

Additional Specially Designed Hitches available for Truck Campers, Long Bed/Ext Cab Trucks, and Maxi/Super Vans - Individual Components can be ordered separately - Call 800/443-2307 for Pricing & Part Numbers

Column A indicates # of holes drilled for installation	<b>1,000 lb. Tongue Weight 10,000 lb. Trailer Weight</b>	<b>2,000 lb. Tongue Weight 20,000 lb. Trailer Weight</b>
Column B indicates if standard Spare Tire remains in original location	Order 1 of each, Vehicle Kit, Trailer Kit, & Mounting Kit to complete a new installation	Order 1 of each, Vehicle Kit, Trailer Kit, & Mounting Kit to complete a new installation

# 2009 PullRite Receiver Hitch Application Chart

70 Degree Turning Radius Models				PullRite Part Numbers			PullRite Part Numbers		
Chevrolet Sport Utility Vehicles	Year	A	B	Vehicle Kit	Trailer Kit	Mounting Kit	Vehicle Kit	Trailer Kit	Mounting Kit
Tahoe (not Denali) (includes added center receiver)	00-02	2	Yes	0047	0113	004710	n/a	n/a	n/a
Suburban	92-99	No Drill	n/a	0040	0113	004010	0041	0113	004110
Suburban ¾ Ton (includes added center receiver) *	00-05	No Drill	Yes	0045	0113	004510	0046	0114	004610
Suburban ½ Ton (includes added center receiver) *	00-05	2	Yes	0048	0113	004810	n/a	n/a	n/a
Suburban ¾ Ton Quadra-steer (includes added center receiver) *	03-04	No Drill	Yes	0100	0113	010010	n/a	n/a	n/a
Suburban ¾ Ton with emissions (included added center receiver)*	2007	No Drill	Yes	2001	0113	200110	2002	0113	200210
Van (Full Size)	97-02	No Drill	Yes	0032	0113	003210	n/a	n/a	n/a
* Call PullRite Customer Service at 800-443-2307 for fit information if equipped with emissions control box									
Chevrolet Light Duty Trucks									
6' Bed, Std & Extended Cab Styles, ½ & ¾ Ton	88-98	4	No	0070	0113	007010	0069	0114	006910
6' Bed, Std & Extended Cab Styles, ½ & ¾ Ton	99-05	No Drill	No	0070	0113	007012	0069	0114	006912
8' Bed, Std & Extended Cab Styles, ½ & ¾ Ton	99-05	No Drill	No	0070	0113	007011	0069	0114	006911
Chevrolet Heavy Duty Trucks									
6' Bed, Std, Ext & Crew Cab Styles, ¾ Ton (includes added center receiver)	01-09	No Drill	Yes	0049	0113	004910	0050	0114	005010
8' Bed, Crew & Extended Cab Styles, ¾ & 1 Ton (tapered frame)	92-00	4	No	0086	0113	008610	0089	0114	008910
8' Bed, Crew & Extended Cab Styles, ¾ & 1 Ton (includes added center receiver)	01-08	2	Yes	0037	0113	003710	0038	0114	003810
Dodge Vans									
Full Size, Ram Van	94-04	2	Yes	0054	0113	005412	n/a	n/a	n/a
Full Size, Maxi Van	78-04	6	n/a	0056	0113	005610	n/a	n/a	n/a
Dodge Trucks									
6' Bed, Std, Club, & Quad Cab, ½ & ¾ Ton (except '02 ½ Ton) (includes added center receiver)	94-02	No Drill	Yes	0052	0113	005210	0053	0114	005310
6' Bed, Quad Cab, Mega Cab, ¾ & 1 Ton	03-09	No Drill	Yes	0092	0113	009210	0093	0114	009310
8' Bed, Std, Club, Quad Cab ½, ¾ & 1 Ton (except 2002 ½ Ton)	94-02	2	Yes	0064	0113	006410	0065	0114	006510
8' Bed, Quad Cab, ¾ & 1 Ton	03-09	No Drill	Yes	0072	0113	007210	0073	0114	007210
Ford Sport Utility Vehicles & Vans									
Excursion (4wd only)	00-04	4	Yes	0007	0113	000710	0006	0114	000610
Van (Full Size) (2K/20K Hitch for E-350 Only)	92-05	Up to 2	Yes	0020	0113	002010	0021	0114	002110
Super Van (Full Size, Ext'd) (2K/20K for E-350 Only)	92-05	4	No	0022	0113	002210	0023	0114	002310
Ford Trucks									
6' & 8' bed, F-150 & F-250 Light Duty	97-03	2	Yes	0025	0113	002510	n/a	n/a	n/a
6' & 8' bed, F-250 & F-350 Super Duty, Super Cab & Crew Cab (includes added center receiver)	99-08	No Drill	Yes	0026	0113	002610	0027	0114	002710
F-150, including SuperCrew (4wd only)	04-08	2	Yes	0015	0113	001510	n/a	n/a	n/a
Nissan Trucks									
Titan, King Cab & Crew Cab (includes added center receiver)	04-05	No Drill	Yes	0002	0113	000210	n/a	n/a	n/a
Toyota Trucks									
Tundra (includes added center receiver)	01-04	No Drill	Yes	0001	0113	000110	n/a	n/a	n/a