



# Quick Connect Capture Plates

## Demco, 5th Airborne, Rotoflex

(Part# 331750, 331751, and 331756)

1. Locate the correct illustration to the right, that corresponds to your Quick Connect Capture Plate.
2. Slide the Quick Connect Capture Plate onto the pin box plate.
3. Apply red label Loctite® to the threads of each set screw.
4. Using an allen wrench, thread the set screws flush against the outside wall of the Capture Plate.
5. The set screws will not contact the body of the king pin box, they will suspend the Capture Plate on the king pin plate lip.
6. The Quick Connect Capture Plate will be positioned correctly for towing, once you have hooked up.

