

# TEMPLATE BUYING GUIDE



HITCH MODELS	VEHICLE FIT YEARS	VEHICLE MAKE & MODELS	MOUNTING KIT PART#	TEMPLATE PART#
<b>#1200 # 0800 Super 5<sup>th</sup> w/ SuperRails</b>				
	2001 - 2010	Chevy 2500 & 3500 HD	0843	<b>08530000</b>
	1999 - 2012	Ford F250 & F350	0841	<b>08510000</b>
	1995 - 2002	Dodge (except 2002-2004 1500)	0842	<b>08520000</b>
	2003 - 2010	Dodge 2500 & 3500 (except 3500 2WD)	0844	<b>08540000</b>
<b>SuperRail Template Set for Installers</b> <i>(includes all templates above)</i>				<b>084000</b>
<b>#1200 # 0800 Super 5<sup>th</sup> w/ SuperBrackets</b>				
	All trucks w/ UMK or SuperBracket Kits		0820 UMK 0822, 0824, 0826, 0827, 0828	<b>0899</b>
<b>#0503 &amp; #0515 Super 5<sup>th</sup></b>				
	All trucks		0520 & 0521 UMK 0517, 0522, 0524, 0525, 0526, 0527, 0528, 0530, 0531	<b>0589</b>
<b>#1900, #2100 ISR Super 5<sup>th</sup> &amp; #2700 &amp; #2900 ISR SuperGlide</b>				
	All trucks equipped with our Industry Standard Rail (ISR) Series hitches		2720 UMK	<b>27200000</b>
<b>#3100 SuperGlide</b>				
	2004 - 2007	Chevy 1500 (5'8" bed, except 2007 current body style)	3114	<b>31140000</b>
	2007 - 2011	Chevy 1500 (5'8" bed, current body style only)		
	2004 - 2008	Ford F150 SuperCrew	3113	<b>31110000</b>
	2001 - 2003	Ford F150 SuperCrew	3111	<b>31110000</b>
	2004 - 2011	Nissan Titan (short beds)	3115	<b>31150000</b>
	2001 - 2006	Toyota Tundra (standard extra cab)	3112	<b>31120000</b>
	2007 - 2011	Toyota Tundra (Crew Max and 5'8" bed only)	3118	<b>31180000</b>
<b>3100 Template Set for Installers</b> <i>(includes all templates above)</i>				<b>310000</b>
<b>#4100 &amp; #4400 SuperGlide</b>				
	1999 - 2010	Chevy 2500 & 3500	3315, 3345	<b>* 33150000</b>
	1999 - 2007	Chevy 1500 (6-1/2' bed, except 2007 body style)	3315, 3345	<b>* 33150000</b>
	2007 - 2011	Chevy 1500 (new body, 6-1/2')	4423	<b>33150000</b>
	2011 - 2012	Chevy 2500 & 3500	4427, 4428	<b>44270000</b>
	1995 - 2002	Dodge (except 2002 1500)	3316, 3346	<b>33160000</b>
	2003 - 2012	Dodge 2500 & 3500	3318, 3319, 3349	<b>* 33180000</b>
	2002 - 2008	Dodge 1500	3318, 3319, 3349	<b>* 33180000</b>
	1997 - 2003	Ford LD	3312, 3342	<b>33120000</b>
	1999 - 2012	Ford Super Duty	3313, 3343	<b>* 33130000</b>
	1988 - 1998	Ford Super Duty	3311, 3341	<b>33110000</b>
	2004 - 2011	Ford LD	3321, 3361	<b>33210000</b>
	2007 - 2011	Toyota Tundra (extra cab, 6-1/2')	4421	<b>33400000</b>
<b>UMK Template</b>			3340	<b>* 33400000</b>
<b>3300 Template Set for Installers</b> <i>(includes the 4 templates listed above marked with an *)</i>				<b>330000</b>
<b>#3500 &amp; #3600 SuperGlide</b>				
	1 Template covers ALL applications for 20K/24K SuperGlide installations			<b>350000</b>

13790 East Jefferson Blvd. • Mishawaka, IN 46545  
 (574) 259-1520 • (800)-443-2307  
 Fax (574) 258-0289  
 info@pullrite.com • www.pullrite.com

(rev. 01-20-12)