



Quick Connect Capture Plate Lippert Rhino Box

Part# 331723

Instructions

1. Confirm the "A, B and C" measurements of your trailer's king pin plate listed in the Quick Connect Capture Plate Chart before proceeding (visit our website at www.pullrite.com for Fit Chart details).
2. While holding the Capture Plate in place up on the trailer's king pin, tighten the 1/2" Set Screw and Spacer Block against the king pin box.
3. To prevent the Set Screw from backing out, tighten the Flange Nut.
4. Optional -The (2) 3/8" Hex bolts are not necessary to hold the plate in place, but can be used for an extra safety measure in case the 1/2" set screw should somehow loosen. For this measure, tighten bolts with nuts through existing holes on both sides of the Capture Plate.

