



# Quick Connect Capture Plates

## MorRyde

(Part# 331708)

1. Confirm the "A,B and C" measurements of your trailer's king pin plate listed in the Quick Connect Capture Plate Chart before proceeding (visit our website at [www.pullrite.com](http://www.pullrite.com) for Fit Chart details).
2. Holding the Capture Plate in place on the trailer's king pin box, tighten the Set Screw against the king pin.
3. To prevent the Set Screw from backing out, tighten the Hex Jam Nut against the tab on the Wedge. *Do not tighten the hex nut against or toward the king pin.*

