



Gen Y Quick Connect Capture Plate

(Part# 331726)

Instructions

NOTE: Lubricate and pre-screw the Set Screws into the tapped sides of the plate to ensure the threads are free.

1. Slide the Quick Connect Capture Plate flush against the pin box plate with wedge to the side toward the trailer. Clamp in place.
2. Add a split lock washer onto each set screw.
3. Apply red label Loctite® to the threads of each set screw.
4. Using a 9/16" socket wrench, thread the (4) set screws in until flush against the outside wall of the Capture Plate. Tighten to 23 ft. pounds.
5. The set screws will not contact the body of the king pin box, they will suspend the Capture Plate on the king pin plate lip.
6. The Quick Connect Capture Plate will be positioned correctly for towing, once you have hooked up.

