



MOUNTING KITS - ISR SERIES

Our Mounting Kits are better than the "other guy's" and are constructed from high quality materials made here in the USA. Custom Brackets require less drilling and install faster, and our Universal kits fit more trucks without ordering extra kits.









#2900 - 20K #2300 - 24K #3200 - 14K **

NOTE: To determine the total tow capacity of a system,

you must consider the weight ratings of each component in that system. This includes, but may not be limited to, the rating of the tow vehicle, the fifth wheel hitch, and		UNIVERSAL	UNIVERSAL HEAVY DUTY	CUSTOM	CUSTOM HEAVY DUTY	SUPERRAIL
	mounting system. Actual tow capacity of the Il be equal to the lowest rated component.	PullRite#	PullRite#	PullRite#	PullRite#	PullRite#
GM						
2020-2025	2500 & 3500 (No Drill)			2770	2238	2338
2016-2019	2500 & 3500 (No Drill) Designed for easier install			2762	2234	
2011-2019	2500 & 3500 (No Drill)			2724	2226	2328
2001-2016	2500 & 3500 HD	2720	2220			
1999-2010	2500 & 3500 HD			2734	2224	2326
2019-2025	1500 (New Body Style)			2768		
2007-2019	1500 (6-1/2' bed, old body style)	2720		2730		
RAM						
2013-2025	3500 (No Drill)			2742	2242	
2014-2025	2500 (No Drill)			2746	2240	2336
2013	2500 (No Drill)			2740	2232	
2003-2012	2500 & 3500 (*No Drill) Does not fit 3500 w/ overload springs	2720	2220	2736*	2230*	2330*
2016-2025	1500 (Does not fit w/ air bags)			2764		
2009-2015	1500 (Does not fit w/ air bags)			2728		
FORD						
2017-2025	F250 & F350 (No Drill)			2774		
2017-2023	F250 & F350 (No Drill)			2766	2236	2332
2011-2016	F250 & F350 (No Drill)			2738	2228	2324
1999-2016	F250 & F350	2720	2220			2324
1999-2010	F250 & F350			2726	2228	
2021-2025	F150			2772		
2015-2020	F150 (No Drill)			2760		
2004-2014	F150 (No Drill)			2732		
TOYOTA						
2007-2021	TUNDRA (Fits all bed lengths)			2748		

- ALL THE ABOVE KITS FIT LONG OR SHORT BED TRUCKS WITH ANY BRAND ISR HITCH , EXCEPT #3200 SUPERGLIDE WHICH IS DESIGNED FOR SUPER SHORT (5-1/2') BEDS ONLY.
- HD KITS ARE RECOMMENDED FOR HITCHES RATED FOR MORE THAN 20K.

UNIVERSAL KITS include "L" Brackets, ISR Base Rails and Hardware. Heavy Duty kits include ISR HD Base Rails and Hardware

CUSTOM KITS include Custom Mounting Brackets, ISR Base Rails and Hardware. Heavy Duty kits include ISR HD Base Rails and Hardware

SUPERRAIL KITS featuring Clean Bed Technology include totally removable SuperRails and Posts, Mounting Brackets and Hardware for a clean truck bed!

^{**} TO DETERMINE CORRECT SUPER SHORT BED TRUCK/TRAILER COMBINATIONS, GO ONLINE TO PULLRITE.COM/SUPERSHORTBED_HIW.





MOUNTING KITS - TRADITIONAL SERIES

Our Mounting Kits are better than the "other guy's" and are constructed from high quality materials made here in the USA. Custom Brackets require less drilling and install faster, and our Universal kits fit more trucks without ordering extra kits.





#4100 - 16K (left) #4400 - 20K (right) Universal Mounting Kits only applicable for #4100 and #4400 SuperGlide models





UNIVERSAL

SUPER SHORT BED SOLUTION

SUPERRAIL

#3100 - 12K #3100 SuperRail Mounting Kits only applicable to the #3100 Traditional Series SuperGlide

#3100

SUPERRAIL

NOTE: To determine the total tow capacity of a system, you must consider the weight ratings of each component

in that sys	in that system. This includes, but may not be limited to, the rating of the tow vehicle, the fifth wheel hitch, and the			SUPERRAIL	
	unting system. Actual tow capacity of the system will be equal to the lowest rated component.	PullRite#	PullRite#	PullRite#	
GM		•	,		
2011-2019	2500 & 3500 (No Drill)		4428		
1999-2010	2500 & 3500	3340	3345		
2007-2019	1500 (6-1/2' bed, old body style)		4423		
1999-2007	1500 (6-1/2' bed, except 2007 mid-year body change)	3340	3345		
2019-2021	1500 (5'8" bed, new body style)			3124*	
2007-2019	1500 (5'8" bed, old body style)			3117*	
2004-2007	1500 (5'8" bed, except 2007 current body style)			3114*	
RAM					
2013	2500 (No Drill)		4440		
2003-2012	2500 & 3500 (No Drill)		3349		
2019-2021	1500 (5'8", new body style, No Drill) Does not fit Ram 1500 w/ factory air suspension			3125*	
2009-2019	1500 (5'7" & 6-1/2' bed, old body style)			3122*	
2002-2008	1500 (No Drill)		3349		
1995-2002	(Except '02 1500)	3340	3346		
FORD					
1999-2016	F250 & F350	3340	4426		
2021	F150 (5'6" bed)			3126*	
2015-2020	F150 (5'6" bed)			3123*	
2004-2014	F150 (6-1/2" bed)		3361		
1997-2003	F150 (6-1/2" bed)	3340	3342		
2009-2014	F150 (5'7" bed)			3119*	
2004-2008	SuperCrew F1			3113*	
2001-2003	SuperCrew F150 (5'6" bed)			3111*	
TOYOTA					
2007-2021	TUNDRA (Double Cab Only, 6-1/2" bed, Universal Rails with Custom Mounting Brackets)	4421			
2001-2006	TUNDRA (Standard Cab)			3112*	
2007-2021	TUNDRA (Crew Max, Super Short Bed (5-1/2" bed only)			3118*	

[•] ALL THE ABOVE KITS FIT 6-1/2' SHORT BED TRUCKS, EXCEPT #3100 SUPERGLIDE WHICH IS DESIGNED FOR SUPER SHORT (5-1/2') BEDS ONLY.

* TO DETERMINE CORRECT #3100 SUPERGLIDE TRUCK/TRAILER COMBINATIONS, GO ONLINE TO PULLRITE.COM/SUPERSHORTBED_HIW.

UNIVERSAL KITS include "bolt to the bed" Baserails, Universal "L" Brackets and Hardware

SUPERRAIL KITS featuring Clean Bed Technology include totally removable SuperRails and Posts, Mounting Brackets and Hardware for a clean truck bed!

#3100 SUPERRAIL KITS featuring Clean Bed Technology include totally removable SuperRails and Posts, Mounting Brackets and Hardware for a clean truck bed!

SINGLE POINT ATTACHMENT HITCHES







MOUNTING HARDWARE

NOTE: In order to determine the total tow capacity of a system, you must consider the weight ratings of each component in that system. Actual tow capacity of the system will be equal to the lowest rated component, including the vehicle tow rating.

PullRite#

	, , , ,					
GM						
2016-2025	2500 & 3500, long and short bed trucks w/ OE tow package	4437				
2008-2025	2500 & 3500, long and short bed trucks w/ aftermarket 2-5/16" gooseneck ball	SEE GOOSENECK MANUFACTURER				
RAM						
2008-2025	2025 2500 & 3500, long and short bed trucks w/ OE tow package 44					
2013-2025	2500 & 3500, long and short bed trucks w/ aftermarket 2-5/16" gooseneck ball	SEE GOOSENECK MANUFACTURER				
FORD						
2008-2025	F250 & F350, long and short bed trucks w/ OE tow package	4437				
2010-2025	F250 & F350, long and short bed trucks w/ aftermarket 2-5/16" gooseneck ball	SEE GOOSENECK MANUFACTURER				

OE PUCK SERIES HITCHES & ACCESSORIES



OEX Series

4700 - 25K OEX Super 5^{TH} for Ford OE Puck trucks 4715 - 25K OEX SuperLite for Ford OE Puck trucks 4800 - 25K OEX Super 5TH for Ram OE Puck trucks 4815 - 25K OEX SuperLite for Ram OE Puck trucks 4900 - 25K OEX Super 5TH for GM OE Puck trucks

4915 - 25K OEX SuperLite for GM OE Puck trucks



OE Puck SuperGlides

2714 - 16K for Ford OE Puck trucks 2715 - 16K for GM OE Puck trucks 2914 - 20K for Ford OE Puck trucks 2915 - 20K for GM OE Puck trucks 2315 - 24K for Ram OE Puck trucks

4500 - 24K for GM OE Puck trucks



OE Puck Super 5th's

1300 - 18K for Ford OE Puck trucks 1400 - 25K for Ford OE Puck trucks 1500 - 18K for GM OE Puck trucks

1600 - 25K for GM OE Puck trucks 1800 - 25K for GM OE Puck trucks OE Puck to ISR Rail Adapters

4439 - 25K for Ram OE Puck trucks 4442 - 20K for Ford OE Puck trucks 4444 - 20K for GM OE Puck trucks

4452 - 25K for GM OE Puck trucks


NOTE: In order to determine the total tow capacity of a system, you must consider the weight ratings of each component in that system. This includes, but may not be limited to, the rating of the tow vehicle, the fifth wheel hitch, and the hitch's mounting system. Actual tow capacity of the system will be equal to the lowest rated component.
lowest rated component.

NOTE: In order to determine the total tow capacity of a system, you must consider the weight ratings of each component in that system. This includes, but may not be limited to, the rating of the tow vehicle, the fifth wheel hitch, and the hitch's mounting system. Actual tow capacity of the system will be equal to the lowest rated component.		OEX SERIES SUPER 5 th	OEX SERIES SUPERLITE	OE PUCK SERIES SUPERGLIDE	OE PUCK SERIES SUPER 5 th	OE PUCK TO ISR RAIL ADAPTERS	
		PullRite#	PullRite#	PullRite#	PullRite#	PullRite#	
GM							
2020-2025	2500 & 3500 for GM trucks w/ OE Puck Mounting System	4900	4915	4500	1800	4452	
2016-2019	2500 & 3500 for GM trucks w/ OE Puck Mounting System			2715 2915	1500 1600	4444	
RAM	RAM						
2014-2025	2500 & 3500 for Ram trucks w/ OE Puck Mounting System	4800	4815	2315	4800	4439	
2013	2500 & 3500 for Ram trucks w/ OE Puck Mounting System	4800	4815	2315	4800	4439	
FORD	FORD						
2010-2025	2500 & 3500 for Ford trucks w/ OE Puck Mounting System	4700	4715	2714 2914	1300 1400	4442	
ALL OE PUC	ALL OE PUCK HITCHES AND ABOVE RAIL ADAPTERS feature Clean Bed Technology for a clean truck bed!						

CAPTURE PLATES - REQUIRED FOR SUPERGLIDE HITCHES

Capture Plates are required for the SuperGlide hitch system. The Capture Plate wedge isolates the king pin from turning in the fifth wheel plate, causing the Cam Assembly to activate and allowing the SuperGlide to move during turns. Most applications slip over the king pin and are held in place by a set screw. To determine your correct Capture Plate:

- 1) Find the manufacturer's name and model number located on your pin box.
- 2) Find the corresponding Quick Connect part number.
- 3) To ensure correct fit, make the following measurements:
 - A: Measure the king pin plate from side-to-side. This is the most important measurement. Be sure this measurement is no more than 1/16" less than the measurement listed in the column below.
 - B: Measure from the leading edge of the king pin to the leading edge of the king pin plate.
 - C: Measure from the rear edge to the leading edge of the king pin plate.





Sizing Chart (recommended)

KING PIN BOX MANUFACTURER	PullRite #	KING PIN BOX	"A"	"B"	"C"		
		MODEL#					
11 (4)		POPULAR BRANDS	42.2/4#	2.2/0"	0.7/01		
Lippert (long)	331704	1621*	12-3/4"	3-3/8"	8-7/8"		
Lippert (long)	331705	1621*	13-1/4"	3-3/8"	8-7/8"		
Lippert (medium)	331705	1116*	13-1/4"	3-1/2"	9-3/16"		
Lippert (long)	331705	1716*	13-1/4"	3-1/4"	8-7/8"		
Lippert Helux	331725	Helux	13-3/16"	6-3/4"	11-13/16"		
Lippert Rhino Box	331723	Rhino	7-3/8"	2-5/16"	7-3/4"		
MOR/ryde (not compatible with Universal or Multi-fit)	331707	Rubber Cushion	13-1/2"	7-5/16"	17-1/2"		
Trailair Rota-Flex / Road Armor (not Universal or Multi-fit)	331760	Most Models	13-5/8"	5"	11-7/16"		
	CON	MON BRANDS					
5th Airborne (medium)	331709	Most Models	10-1/2"	6-7/8"	14-1/4"		
5th Airborne	331759	Most Models	12"	7-7/8"	19-7/8"		
Demco (not Universal)	331750	Most Models	10-3/4"	5"	11-7/8"		
Demco (not Universal)	331751	Most Models	11-1/4"	5-1/8"	12-1/16"		
Dexter	331731	Most Models	12"	5-9/16"	12-1/4"		
Fabex	331720	500's, 765, 770*	13-1/2"	3-1/4"	9-1/4"		
Fabex	331706	Most Models	12"	4-5/8"	11-3/8"		
Gen-Y	331726	Gen-Y	12"	4"	10-15/16"		
Leland	331730	Most Models	14"	5-1/2"	12-1/4"		
Lippert (long)	331711	1621 HD*	12-3/4"	4"	8-7/8"		
Lippert	331710	0719**	12-3/4"	6-3/8"	12-1/4"		
MOR/ryde (not Universal or Multi-fit)	331708	Standard	12-1/2"	4-1/8"	8-7/8"		
Reese Revolution	331721	10K Pin Box	10-1/2"	4-1/4"	11"		
Reese Revolution (*for 16K with spacers)	331722	16K or 21K Pin Box	13" or 12-1/2"	4-1/4"	11-3/4"		
Trailair FlexAir	331761	Most Models	13-1/4"	6-1/8"	12-3/4"		
Trailair Rota-Flex / Road Armor (not Universal or Multi-fit)	331756	Most Models	13-3/8"	5-3/8"	11-7/16"		
Trailair Tri Glide Airbag/Shock Pin Box	331757	Tri Glide Only	12-3/4"	5-15/16"	ALL		
Trailair Airbag/Shock Pin Box	331758	Most Models	13" or 13-3/8"	7-3/8"	13-1/2"		
MULT	ΓΙ-FIT AND U	NIVERSAL CAPTURE PLATES					
Multi-fit Capture Plate	3365	*Fits the indicated pin boxes above 12-3/4" through 13-1/2" & 14"		2-9/16" - 4"	ALL		
Multi-fit Capture Plate	3366	**Fits the indicated pin boxes above 12, 12-1/4", 12 3/4" 5-3, 6-3			ALL		
Universal Capture Plate Kit	3317	3317 INCLUDES: Universal Capture Plate, Fore & Aft Plate Extensions, Knee Braces and Hardware					